



BC 900 S - Gear Case Ass' y




No	Code	Name	Qty	No	Code	Name	Qty
A	010838	Gear Case Ass' y		24			
1		Stop Ring 26	1	25			
2		Stop Ring 10	1	26			
3		Bearing 6000-2RS/P6	1	27			
4		Bearing 6000/P6	2	28			
5		Pinion	1	29			
6		Screw M5X20	1	30			
7		Screw M5X 12	4	31			
8		Bolt M5X12	1	32			
9		Gear Case	1	33			
10		Safety Guard	1	34			
11	10850	Gear	1	35			
12		Gear Shaft	1	36			
13		Bearing 6002—2RS/P6	1	37			
14		Stop Ring 32	1	38			
15		Holder A	1	39			
16	10839	Holder B	1	40			
17	010840	Washer 10	1	41			
18		Left Nut	1	42			
19	010841	Pin 2X16	1	43			
20				44			
21				45			
22				46			
23				47			

BC 900 S - B




No	Code	Name	Qty	No	Code	Name	Qty
B				24			
1	022033	Handle	1	25			
2	10853	Grip Left	1	26			
3		Grip Left	1	27			
4		Bolt M6X25	4	28			
5		Cap, Upper	1	29			
6		Bracket	1	30			
7		Rubber Washer	1	31			
8		Cap, Lower	1	32			
9		Bolt M6X40	4	33			
10				34			
11				35			
12				36			
13				37			
14				38			
15				39			
16				40			
17				41			
18				42			
19				43			
20				44			
21				45			
22				46			
23				47			

BC 900 S - C




No	Code	Name	Qty	No	Code	Name	Qty
C		Clutch Comp.		24			
1	13481	Clutch Drum Comp.	1	25			
2	010723	Stop Ring 35	1	26			
3	10771	Bearing 6202-2RZ/P6	1	27			
4		Stop Ring 15	1	28			
5	010843	Linker	1	29			
6	013436	Rubber Cover	1	30			
7		Screw M5X 12	1	31			
8		Screw M5X25	2	32			
9	010845	Clamp A	1	33			
10	010844	Clamp B	1	34			
11		Screw M6X25	4	35			
12				36			
13				37			
14				38			
15				39			
16				40			
17				41			
18				42			
19				43			
20				44			
21				45			
22				46			
23				47			

BC 900 S - D




No	Code	Name	Qty	No	Code	Name	Qty
D	10842	Pipe Comp.	1	24			
1		Rubber Cover	6	25			
2		Oil-bearing	6	26			
3		Drive Shaft	1	27			
4		Pipe	1	28			
5				29			
6				30			
7				31			
8				32			
9				33			
10				34			
11				35			
12				36			
13				37			
14				38			
15				39			
16				40			
17				41			
18				42			
19				43			
20				44			
21				45			
22				46			
23				47			

BC 900 S - E




No	Code	Name	Qty	No	Code	Name	Qty
E		Guard Ass' y		24			
1	010848	Bracket	1	25			
2		Screw M5X30	2	26			
3		Screw M5X 12	1	27			
4		Screw ST4. 2X16	1	28			
5	13447	Safety Guard	1	29			
6		Screw M5X16	4	30			
7	9799	Guard Ass' y	1	31			
8		Guard	1	32			
9		Screw ST4. 2X16	2	33			
10	17552	Blade	1	34			
11				35			
12				36			
13				37			
14				38			
15				39			
16				40			
17				41			
18				42			
19				43			
20				44			
21				45			
22				46			
23				47			

BC 900 S - F



No	Code	Name	Qty	No	Code	Name	Qty
F	010847	Lever Ass'y		24			
1		Screw ST2. 9X13	1	25			
2		Button	1	26			
3		Spring	1	27			
4		Lock pin	1	28			
5		Hand grip	1	29			
6		Spring	1	30			
7		Box,Right	1	31			
8		Screw ST2. 9X 18	3	32			
9		Screw M5X30	1	33			
10		Cable comp.	1	34			
11		Tube	0.8m	35			
12		Stop Button comp.	1	36			
13		Hand Grip	1	37			
14		Spring	1	38			
15		Box,Left	1	39			
16		Nut M5	1	40			
17				41			
18				42			
19				43			
20				44			
21				45			
22				46			
23				47			

BC 900 S - Engine



No	Code	Name	Qty	No	Code	Name	Qty
1		Screw	1	25		WasherB	1
2		Ratchet	1	26		WasherB	1
3		Start Rope Reel	1	27		Nut M8	1
4		Rope	1	28	10876	IGNITION COIL COMP.	1
5		Recoil Spring	1	29		Cord Comp.	1
6		Start Cover Ass'y	1	30		Bolt M5 x 20	6
7		Screw M5 x 20	7	31		WasherB	2
8		Start Handle	1	32		Spring	1
9		Ring	1	33	010883	Expander	2
10		Spring	1	34		Washer	2
11		Start pole	2	35	24167	Screw Pin	2
12	015417	Starter	1	36		Flash Pan	1
13	013531	Gasket	1	37	010884	Fan Cover	1
14	009827	Start Reel	1	38			1
15	010860	Oil-seal	2	39	020852	Bearing	1
16	010861	Crank Case	1	40	010878	Ring	2
17	017554	Gasket	1	41	010880	Piston Pin	1
18	10558	Bearing 6201/P6	2	42	010879	Piston	1
19	018885	Crank Shaft	1	43	010881	Piston Ring	2
20	32478	Key 3x5x13	1	44	017553	Gasket	1
21		Pin B4x10	4	45	010882	Cylinder	1
22	010875	Crank Case	1	46		Screw M5 x18	4
23		Screw M5 x 30	4	47	010867	Guide Cover Ass'y	1
24	10877	MAGNETO ROTOR COMP	1	48	10866	Spark Plug	1

BC 900 S - Engine

No	Code	Name	Qty	No	Code	Name	Qty
49		Spring	1	97			
50		Plug Cap	1	98			
51		Cap	1	99			
52		Plug	1	100			
53	010868	Cover	1	101			
54	036804	Gasket	1	102			
55	010870	Muffler	1	103			
56		Screw M5 x12	3	104			
57		Bolt	2	105			
58		Nut M5	2	106			
59	10869	Muffler Cover	1	107			
60	010863	Gasket	2	108			
61	010889	Admitting Pipe	1	109			
62	013425	Gasket	1	110			
63	010887	Carburetor	1	111			
64		Choker Handle	1	112			
65		Stop ring	1	113			
66		Nut M4	1	114			
67	012592	Cleaner inside cover	1	115			
68		Screw M5x50	2	116			
69	014028	Choker	1	117			
70		Screw ST4.2X12	1	118			
71	010888	Cleaner Outside Cover	1	119			
72	010865	Filter Net	1	120			
73	013449	Screw	1	121			
74	014027	Bracket	1	122			
75		Rubber Cover	1	123			
76	010871	Cleaner Cover	1	124			
77	13510	Fuel Pipe	1	125			
78	20857	Plug	1	126			
79	13509	Fuel Pipe	1	127			
80		Screw M5 x16	2	128			
81	010885	Fuel Tank	1	129			
82		Chain	1	130			
83		End Cover	1	131			
84		Inside Cover	1	132			
85		Inlet	1	133			
86		Gasket	1	134			
87		Fuel Tank Lid	1	135			
88	010886	Lid Ass'y	1	136			
89		Rubber washer	2	137			
90				138			
91				139			
92				140			
93				141			
94				142			
95				143			
96				144			